

## INSTALLATION ACCESSORIES

Vendor	Description
<b>FIRE CABLE</b>	
<b>F0002</b>	<b>Fire Cable</b> Fire retardant cable 0.5 mm <sup>2</sup> 1 pair 100m roll
<b>F0209</b>	<b>Fire Cable</b> Fire retardant cable 0.8 mm <sup>2</sup> 2 Core 100m roll
<b>F0241</b>	<b>Fire Cable</b> Fire retardant cable 0.8 mm <sup>2</sup> 4 Core 100m roll
<b>F0003</b>	<b>Fire Cable</b> Fire retardant cable 1 mm <sup>2</sup> 1 pair 100m roll
<b>F0210</b>	<b>Fire Cable</b> Fire retardant cable 1.5 mm <sup>2</sup> 4 Core 100m roll
<b>BATTERIES</b>	
<b>B0831</b>	<b>Ultratech Battery 12VDC 7Ah</b> Ultratech Battery 12VDC 7Ah
<b>B1017</b>	<b>Energys Battery 12VDC 7Ah</b> Energys Battery 12VDC 7Ah 100% depth of discharge 250 cycles, 50% depth of discharge 550 cycles, 30% depth of discharge 1200 cycles, Life time 3 to 5 years
<b>B1003</b>	<b>Ultratech Battery 12VDC 18Ah</b> Ultratech Battery 12VDC 18Ah
<b>B1005</b>	<b>Ultratech Battery 12VDC 24Ah</b> Ultratech Battery 12VDC 24Ah
<b>B1007</b>	<b>Ultratech Battery 12VDC 40Ah</b> Ultratech Battery 12VDC 40Ah

## ANALOGUE ADDRESSABLE CONTROL PANELS

### KENTEC EN54 APPROVED PANELS


#### Syncro Series

<b>V81162M2</b>	<b>Syncro AS 2 Loop Control panel</b> Analogue Addressable Control Panel: Argus Protocol, Surface mount including loop card
<b>ENV6300403</b>	<b>Syncro Analogue 4 Loop Control panel</b> Addressable Control Panel, 0 Zone LED's: Surface mount including loop cards
<b>K232SYN</b>	<b>Thermal Printer Retrofit Kit</b> Thermal Printer Retrofit Kit
<b>S560</b>	<b>Syncro I/O - 16 Channel I/O board</b> Syncro I/O - 16 Channel I/O board
<b>S547</b>	<b>Syncro I/O - 8 Way Relay Extender Board</b> Syncro I/O - 8 Way Relay Extender Board
<b>S546</b>	<b>Syncro I/O - 6 Way Sounder Extender Board</b> Syncro I/O - 6 Way Sounder Extender Board



SYNCRO CONTROL PANEL

Vendor	Description
<b>KENTEC EN54 APPROVED PANELS</b> <i>(continued)</i>	
<b>S545</b>	<b>Syncro I/O - 4 Way Conventional Detection Zone Module</b> Syncro I/O - 4 Way Conventional Detection Zone Module
<b>K67000M1</b>	<b>Syncro View Local LCD Repeater Panel: Surface</b> Syncro View, Local LCD Repeater Panel no network card needed
<b>K68000M1</b>	<b>Syncro Focus, 3 button version: Surface</b> Syncro Focus LCD Repeater Panel (Network card needed for panel)
<b>S555</b>	<b>Syncro Fault Tolerant Network Interface Card</b> Syncro Fault Tolerant Network Interface Card
<b>X187LS</b>	<b>Software Download Lead (Compatible with all Panels):</b> Software Download Lead (Compatible with all Panels): Economy
<b>S559</b>	<b>Multiple Input Output Unit (MIOU) - Module only</b> Multiple Input Output Unit (MIOU) - Module only
<b>K553</b>	<b>Zone LED's extender kit: 16 Zone Kit</b> Zone LED's extender kit: 16 Zone Kit
<b>K554-48</b>	<b>Zone LED's extender kit: 48 Zone Kit</b> Zone LED's extender kit: 48 Zone Kit
<b>K554-96</b>	<b>Zone LED's extender kit: 96 Zone Kit</b> Zone LED's extender kit: 96 Zone Kit



SYNCRO ANALOGUE ADDRESSABLE SYSTEM

ADI is a tradename of Honeywell Southern Africa (Pty) Ltd. October 2007  
ADI reserves the right for data changes and/or printing errors. E. & O.E.