

SOFTWARE

Vendor	Description
KENTEC EN54 APPROVED PANELS	
Syncro Series	
G1001	Syncro Guide: Single Panel Package Syncro Guide: Single Panel Package
G1004	Syncro Guide: 4 Panel Package Syncro Guide: 4 Panel Package
G1008	Syncro Guide: 8 Panel Package Syncro Guide: 8 Panel Package
G1016	Syncro Guide: 16 Panel Package Syncro Guide: 16 Panel Package
G1032	Syncro Guide: 32 Panel Package Syncro Guide: 32 Panel Package
G1064	Syncro Guide: 64 Panel Package Syncro Guide: 64 Panel Package

ANALOGUE ADDRESSABLE CONTROL PANELS

C-TEC EN54 APPROVED PANELS	
C-Tec XFP Series	
XFP501E/X	XFP Networkable 1 loop Analogue panel, 16 zone , 1.4amp PSU, code entry XP95/ Discover protocol XFP Networkable 1 loop Analogue panel, 16 zone , 1.4amp PSU, code entry XP95/Discover protocol
XFP501/X	XFP Networkable 1 loop Analogue panel, 32 zones , 3amp PSU, code entry, XP95/ Discovery protocol XFP Networkable 1 loop Analogue panel, 32 zones , 3amp PSU, code entry, XP95/Discovery protocol
XFP502/X	XFP Networkable 2 loop Analogue panel, 32 zones, 3amp PSU, code entry, XP95/ Discovery protocol XFP Networkable 2 loop Analogue panel, 32 zones, 3amp PSU, code entry, XP95/Discovery protocol
AFP711	AFP/XFP Network communication card, one needed per master AFP/XFP Network communication card, one needed per master
AFP709	AFP/XFP Printer kit including printer, lead and socket AFP/XFP Printer kit including printer, lead and socket
XFP510	XFP fully functional 32z repeater panel c/w PSU, all protocols, code entry XFP fully functional 32z repeater panel c/w PSU, all protocols, code entry
XFP507	XFP Upload download software XFP Upload download software

Vendor

Description

XLS 50e & 60e EN54 APPROVED CONTROL PANELS**Honeywell XLS 50e & 60e Series**

F0149	XLS50e XLS50e 1-2 loop control panel, 230 Vac and 2 sounder circuits. Order loop card separately. 400 x 400 x 135 mm (HxWxD).
F0150	XLS60e XLS60e 1-5 loop control panel, 230 Vac and 4 sounder circuits. Order loop card separately. 500 x 500 x 195 mm (HxWxD).



XLS60E CONTROL PANEL

INTERNAL EXPANSION MODULES**Honeywell XLS 50e & 60e Series**

F0168	Loop Card TC800/XLS60 Honeywell LIB Loop Card TC800
F0162	Loop Card Hochiki Loop Card Hochiki
F0166	Loop Card Apollo Discovery Loop Card Apollo Discovery
F0167	Loop Card System Sensor Loop Card System Sensor
F0158	Loop Card Nittan Loop Card Nittan
F0159	Loop Card Apollo Loop Card Apollo
F0151	RS485 Card RS485 Card



LOOP CARD TC800/XLS60 HONEYWELL LIB

F0152	RS232 Card RS232 Card
F0169	20 Zone Expander Board For XLS60e 20 Zone Expander Board For XLS60e
F0170	60 Zone Expander Board For XLS60e 60 Zone Expander Board For XLS60e
F0160	Internal printer module On Board Printer

EXTERNAL EXPANSION MODULES**Honeywell XLS 50e & 60e Series**

F0153	4 way, programmable relay module, pcb only Requires an RS485 card to be fitted in the control panel.
F0154	4 way, programmable sounder module, pcb only Requires an RS485 card to be fitted in the control panel.

Vendor	Description
EXTERNAL EXPANSION MODULES <i>(continued)</i>	
F0156	8 way, programmable input module. pcb only Requires an RS485 card to be fitted in the control panel.
F0163	24Vdc 5 A PSU/charger Boxed with space for 24 Ah batteries. 500 x 500 x 180mm (H x W x D)
F0161	Modbus Interface Unit Modbus Interface Unit
F0155	Sounder booster PSU Enclosure comprising 24Vdc PSU/Charger and single sounder circuit controller. 500 x 500 x 180mm (H x W x D).
F0164	24Vdc 5 A PSU/charger Without enclosure.
F0165	40 Way Mimic Driver Card 40 Way Mimic Driver Card
F0157	Hi-485 communication module, pcb only Requires an RS485 card to be fitted in the control panel.
REPEATER PANELS	
Honeywell XLS 50e & 60e Series	
F0147	XLS60e-FR Repeater Active XLS60e-FR Repeater Active
F0148	XLS60e-BR Repeater Passive XLS60e-BR Repeater Passive
F0128	Bezel For XLS60e Repeaters Bezel For XLS60e Repeaters
SEMI FLUSH BEZEL KITS	
Honeywell XLS 50e & 60e Series	
F0179	XLS60e Bezel XLS60e Bezel
F0178	XLS40e/50e Bezel XLS40e/50e Bezel
SOFTWARE	
Honeywell XLS 50e & 60e Series	
F0171	Interface lead For programming all Morley-IAS control panels.
F0172	Engineer's SPK (Software Programming Kit) Engineer's SPK (Software Programming Kit). CD containing Fire 6, Fire 5, Fire 4, Fire 3 and Dimension configuration tools.
F0173	Visualeyez Graphics Workstation - Basic Edition Visualeyez Graphics Workstation - Basic Edition. PC based mimic panel. English Only
F0174	Visualeyez Graphics Workstation - Standard Edition Visualeyez Graphics Workstation - Standard Edition. For connection to a single network with up to 9 control panels. English Only.



XLS60E-FR REPEATER ACTIVE

Vendor**Description****SOFTWARE** *(continued)*

F0175	Visualeyez Graphics Workstation - Standard Edition including TCP/IP Visualeyez Graphics Workstation - Standard Edition including TCP/IP Groups. For connection to a single network with up to 9 control panels. English Only.
F0176	Visualeyez Graphics Workstation - Premium Edition Visualeyez Graphics Workstation - Premium Edition. For connection to a single network with up to 99 panels. English Only.
F0177	Visual Eyes Premium Edition with TCP/IP Groups Visual Eyes Premium Edition with TCP/IP Groups

XLS 80e EN54 APPROVED CONTROL PANEL**Honeywell XLS 80e Series**

F0136	XLS80e 2 loop intelligent fire alarm panel Fixed 2 loop intelligent fire alarm panel, fully assembled. LPCB Approved. 3A P.S.U. Space for up to 12Ah batteries. H:400mm W:500mm D:122mm.
F0137	XLS80e 4 loop intelligent fire alarm panel 4 LOOP intelligent fire alarm panel with 4.5A power supply (including 020-565-001 software upgrade kit for upgrading to software version 4.xx). LPCB approved. Kit includes: 1 x 020-538, 1 x 020-579, 1 x 020-543, 1 x 020-588, 1 x 020-474-009, 1 x 020-480-009, 1 x 020-485-009, 1 x 020-481-009. Space for up to 38Ah batteries. H:620mm W:500mm D:220mm.
F0138	XLS80e 6 loop intelligent fire alarm panel 6 LOOP intelligent fire alarm panel with 4.5A power supply (including 020-565-001 software upgrade kit for upgrading to software version 4.xx). LPCB approved. Kit includes: 1 x 020-538, 2 x 020-588, 1 x 020-579, 1 x 020-543, 1 x 020-474-009, 1 x 020-480-009, 1 x 020-481-009, 1 x 020-485-009. Space for up to 38Ah batteries. H:620mm W:500mm D:220mm.
F0139	XLS80e 8 loop intelligent fire alarm panel 8 LOOP intelligent fire alarm panel with 7A power supply (including 020-565-001 software upgrade kit for upgrading to software version 4.xx). LPCB approved. Kit includes: 1 x 020-538, 3 x 020-588, 1 x 020-579, 1 x 020-543, 1 x 020-472-009, 1 x 020-480-009, 1 x 020-548, 1 x 020-541-009. Space for up to 78Ah batteries. H:400mm W:500mm D:122mm. P.S.U.: H:510mm W:680mm D:241mm.

MAIN MODULES**Honeywell XLS 80e Series**

F0111	XLS80e Equipment Kit, 2 - 8 loops XLS80e Equipment Kit, 2 - 8 loops. LPCB approved.
--------------	---

EXTENSIONS CHASSIS**Honeywell XLS 80e Series**

F0117	Extension Chassis Kit LED indications for Zones 1-64. Space for internal printer (020-644-009).
	Extension Chassis Kit LED indication for Zones 65-128. Space for internal printer (020-644-009).
F0129	256 Zone LED Display Extension Kit 256 Zone LED Display Extension Kit. Requires double extension space and cover.
F0140	XLS 80E Extension Chassis Extension Chassis with PRN-ID Printer Module Kit
F0132	PRN-ID Printer kit for XLS range PRN-ID Printer kit for XLS range.

Vendor	Description
POWER SUPPLIES AND ACCESSORIES	
Honeywell XLS 80e Series	
F0134	PSU 3A Power Supply for XLS80e PSU 3A Power Supply for XLS80e
F0125	PSU 7A Power Supply PSU 7A Power Supply. 4.5A or 7A user selectable. 020-541-009 external PSU cabinet to be ordered separately when used in 7A mode. Requires DTP (020-543).
F0113	Dual Transmission Path Board Kit Dual Transmission Path Board Kit, Required with PSU7A Kits.
F0114	Optional Status Indication Board Kit for 7A PSU Optional Status Indication Board Kit for 7A PSU..
F0112	XLS80e 7 Amp PSU/78AH Battery Cabinet Kit XLS80e 7 Amp PSU/78AH Battery Cabinet Kit
EXPANSION BOARDS	
Honeywell XLS 80e Series	
F0115	XLS80e Dual TC800 Loop Board Kit (E-LIB Card) XLS80e Dual TC800 Loop Board Kit (E-LIB Card), Intelligent E-LIB Card with microprocessor
F0126	XLS80e Dual TC800 Loop Board Kit XLS80e Dual TC800 Loop Board Kit
F0103	XLS80e Isolated RS232 Module Kit XLS80e Isolated RS232 Module Kit.
F0104	XLS80e Isolated RS485 Module Kit XLS80e Isolated RS485 Module Kit, 1 x needed for Repeaters & ID ² Net
NETWORK MODULES	
Honeywell XLS 80e Series	
F0096	Network Gateway Unit (NGU) Network Gateway Unit (NGU). Complete with enclosure, network card, DC/DC converter and space for 12Ah batteries.
F0133	XLS80e network gateway module (NGM) XLS80e network gateway module (NGM). 1 NGM required per XLS80e in an ID2NET network.
F0131	PCA dual port PCA dual port. Fiber optic interface card. Only one required per MGM for fiber - fiber or fiber - wire.
REPEATERS AND MIMIC PANELS	
Honeywell XLS 80e Series	
F0095	XLS80-FR Active Repeater XLS80-FR Active Repeater. 240 x 60 Graphic LCD. Requires external power source and (RS485 communication card to be installed in control panel), Up to 31 repeaters, up to 4 repeaters can be run of control panel auxiliary, up to 6 repeaters can available with active keypad.
F0123	IDR-M Mimic control PCA Kit IDR-M Mimic control PCA Kit. Supports up to 8 Mimic Drivers. Requires external 24Vdc power source.

Vendor	Description
REPEATERS AND MIMIC PANELS <i>(continued)</i>	
F0124	IDR-MD Mimic Driver and termination board PCA Kit IDR-MD Mimic Driver and termination board PCA Kit. Provides 64 LED's or Relay Outputs. Up to 8 Mimic Drivers can be daisy-chained. Requires Mimic control PCA Kit and external 24Vdc power source.
F0128	Semi-Flush Mounting Bezel kit for IDR Series Repeaters Flush Mounting Bezel for IDR Series Repeaters. Black/Grey. H:218mm W:307mm D:60mm. Hole size: H:170mm W:260mm.

PRODUCT LITERATURE & TOOLS

Honeywell XLS 80e Series

F0116	XLS80e Windows off-line configuration tool Windows based Off-line Configuration tool kit, including manual for panel software 4.xx
F0130	XLS80e MIMIC Drive off-line configuration tool XLS80e MIMIC Drive off-line configuration tool.
F0118	XLS80e Software Upgrade Kit Used to upgrade the ID2000/ ID3000 to ID ² net to the current version 4.xx and to use the Windows™ Support Tool and Loop Booster.
F0135	Kit, XLSNET diagnostic tool Kit, XLSNET diagnostic tool

ACCESSORIES & SPARE PARTS

Honeywell XLS 80e Series

F0119	XLS80e Base PCA Assembly Kit XLS80e Base PCA Assembly Kit.
F0120	XLS80e Base CPU PCA Assembly Kit XLS80e Base CPU PCA Assembly Kit.
F0121	240x64 Pixel LCD Kit 240x64 Pixel LCD Kit. Used with ID3000 series panels only.
F0122	XLS80e display Plate With 240x64 Pixel LCD Assembly Kit XLS80e display Plate With 240x64 Pixel LCD Assembly Kit.
F0143	XLS80e extended panel printer cable XLS80e extended panel printer cable, 2m. Required when the printer is installed in the back box extension.
F0142	XLS80e extended LED extension cable XLS80e extended LED extension cable, 2m. Required when the extension chassis is installed in the back box extension.
F0141	Paper roll Replacement printer paper roll.

BACK BOXES, COVERS & BEZELS

Honeywell XLS 80e Series

F0100	Standard Back box Kit, LT/GY Standard Back box Kit, LT/GY
F0101	Extended Deep Back box Kit. LT/GY Extended Deep Back box Kit. LT/GY
F0102	XLS80e Double extended deep back box, light grey XLS80e Double extended deep back box, light grey